

GENERAL FITTING GUIDE

PARKING BRACKET, FLEX & HANDSET

Important information

(Please leave this installation & user guide with the end user)

This installation guide is for all parking brackets with integrated shower handset holders.

Prior to making the water connection to the inlet feed, please make sure that the supply pipe work has been flushed through to remove any debris.

Safety

We recommend that this product is fitted by a fully qualified installer. The installation must comply with all current water regulations. In order for this product to operate as designed it must be installed and commissioned as stated in this manual.

Aftercare

- When cleaning the product please do not use a substance that could possibly damage the surface finish. We recommend that soapy water with a mild detergent is used.
- Please take care not to damage the surface finish of the product. The finish is polished chrome and can be easily marked.

Installation

Prepare a suitable location as the fixing point for parking bracket outlet elbow, using an appropriate plumbing connector (not supplied) for the water feed to the outlet elbow connecting tube.

Connect the shower hose to the shower handset, and locate this in the integrated parking bracket. After securing everything in place, check for any leaks.