

FLEXI-SEAL

INSTALLATION INSTRUCTIONS

DO NOT USE IN CONJUNCTION WITH ACETOXY BASED SILICONE SEALANT.

- Ensure the application surface is clean and free from dust.
- Carefully peel the protective film from the Flexi-Seal adhesive.
- Firmly apply the adhesive section of the seal to the application surface as per the diagrams opposite, ensuring there are no wrinkles or bumps.
- **DO NOT STRETCH THE SEAL WHEN APPLYING.**
- Install the shower tray/bath into situ as normal.
- Fit tiles or panelling over the top of the Flexi-Seal as per the diagram opposite.

