

Safety notes general

- Children and adults with reduced physical, mental and/or sensory capabilities may not use the product unattended.
- Persons under the influence of drugs or alcohol may not use the product.



- There is a risk of burning when removing limescale from the steam generator. Allow the steam generator to cool and follow the instructions in the product information.

- There is a risk of burning or scalding at the steam outlet in the steam room.

- No other electrical devices that produce steam or moisture may be used in the steam room.
- All functions will stop immediately if there is an operational interruption. The light will turn off after 60 seconds.
- No other electrical
- Cleaning:
Control unit, see manufacturer's instructions.

Applications/function

- Using the modules Music/Light/Steam.

Installation instructions

- Installation may only be performed in rooms that are frost-proof.
- The **current version** of the app required for using the system **must** be installed on the control unit in advance:
 - Using a wireless network connect directly to the App Store with the control unit (an account with the provider is required).
 - For Apple: Using iTunes in the iTunes Store (iTunes must be installed on the computer and an account with Apple is required).
 - For Android: From the Google Play Store (an account with Google is required).
- Using a QR code:

Apple



Android



- Connect using the *Bluetooth*® adapter.

Using the GROHE App

The app is the central operating unit to control the connected modules.

General instructions and settings for the control unit are described in the manufacturer's instructions.

The following pages describe how to commission, configure and operate the SPA module using the control panel.

Main symbols:



On/Off switch



Main menu



Configuration



Back



Profile



Music



Light



Steam

Icons:



Start music



Pause music



Next song



Previous song



Shuffle



Replay



Auto steam start



Lighting scheme

Commissioning




Use the On/Off switch to start the app.




A start-up animation appears.

Demo mode




If the control unit is **not** connected to the operating panel it starts in demo mode. In demo mode only a limited number of functions are shown so that users can familiarise themselves with the app.

Managing connections



If a connection to a different control device already exists a message to this effect will appear. To change the control unit first disconnect the connected device or deactivate *Bluetooth*[®]. After 10 seconds the new device can be connected.



A message will appear if the connection is lost during use.

Main menu



Note:
The main menu appears as soon as the start-up animation finishes.

The main On/Off, Configuration and Profile icons appear in the main menu as well as those for the connected components (Music, Light, Steam). Click on the icon for the function you wish to use. Active functions are displayed as pulsating icons.

Configuration menu



Configuration options:

- Icon Text for the on or off icons
- Hotel Mode on or off
- Icon Colour white or orange
- Language G/GB/F/E

- Temperature in Celsius (°C) or Fahrenheit (°F)
- Reset: Reset all settings that were set individually


Music menu




Example playlist:

Select the song:

- (A) List of Artists
- (B) List of Playlists
- (C) List of synchronised Audiobooks
- (D) List of synchronised Albums



After you have made your selection you automatically enter the play menu.




For use, see Operating Icons, page 1.

Slider: volume control

Icons (highlighted using colours when activated):
Shuffle, Replay

Light menu



Click the **Light** icon.

The last configuration used is shown.




Using the light point you can choose a new light colour. Use the slider to change the light intensity.

By pressing the **Light** icon you switch off the light.

By pressing the **Lighting Scheme** icon you start the preconfigured lighting program.

Steam menu



Steam duration:

The duration for the steam can only be set when steam has been deactivated.

Slider to the left: down to 0 minutes

Slider to the right: up to 60 minutes



Steam temperature:

Steam temperature can be changed at any time.

Slider to the left: down to 38°C

Slider to the right: up to 55°C

Click the Steam icon to start the steam generator.



Warming-up:

The warm-up phase begins.

During the warm-up phase the **Steam** icon is inactive.



As soon as the steam room reaches a temperature of 38°C or ten minutes have passed the **Steam** icon becomes active.



Start steam:

Click the **Steam** icon again to start a steam bath with the preconfigured steam duration and temperature.

Programmable start time



In the steam menu press the **auto steam start** icon and confirm the message that follows with **Yes**.




As shown in the steam menu set the steam duration, temperature and start time and then press the **auto steam start** icon.



Confirm the settings.

The **auto steam start** icon is highlighted in colour if a start time has been set.



To deactivate the start time press the coloured **auto steam start** icon and confirm the message that follows.

Create profile



Note:
Max. 9 profiles are possible.

Press the Profile icon to enter the Profile menu.



Press the **Plus** icon to create a new profile and then give it a profile name.

When you press Finish to confirm you automatically enter the Profile Configuration.

Configure profile



In the Configuration menu select the parameters to set.

- Steam temperature
- Steam duration
- Light Colour
- Light Intensity



- Song
- Music Settings




Steam configuration:
(Example: temperature)

Select the value to set (Duration, Temperature) and adjust it using the slider.



Light configuration:

Select the value to set (Light Colour, Light Intensity) and adjust it using the slider or use the preconfigured light settings via the **Lighting scheme** icon.



Music configuration:

Select the song:

- (A) List of Artists
- (B) List of Playlists
- (C) List of synchronised Audiobooks
- (D) List of synchronised Albums




When you have made your selection you automatically enter the play menu:

Set the Volume, Shuffle or Replay.

Manage Profile



Press the Profile icon to enter the profile selection.



Select the desired profile.



Select the desired action.



Start:

Start (Activate profile)/Stop (Deactivate profile)

The name of the activated profile is shown in the main menu.

Click the icon for the function you wish to use (Music/Light/Steam).

Active functions are displayed as pulsating icons.



Edit:

Use the **Edit** icon to enter the Configuration menu, see Configure Profile, Page 15.



Delete:

Confirm deletion of the profile.

Hotel Mode



Note:

Pressing the On/Off switch symbols or Main Menu will cause the settings to be lost.

To start Hotel Mode set the slider to **I** and confirm using the **Back** icon.

The icons for the connected components will appear in the main menu (Music, Light, Steam) and the On/Off switch will appear in the main menu.




Note:

Press the On/Off switch for 10 seconds to leave this mode.

Click on the icon for the function you wish to use. Active functions are displayed as pulsating icons.



Light


Press icon 

When the **Light** function is activated one of the preconfigured lighting schemes (Multi/Morning/Evening) must be selected.

The preconfigured settings can be changed by pressing the **Music** or **Steam** icon for 10 seconds.



Music:


Press icon  for 10 sec.

Select the song:

- (A) List of Artists
- (B) List of Playlists
- (C) List of synchronised Audiobooks
- (D) List of synchronised Albums



Steam:

Press icon  for 10 sec.

Set the desired temperature using the slider and confirm using the **Back** icon.



When the **Steam** function is activated the warming-up phase starts. (**Steam** icon remains inactive until preconfigured temperature is reached).

Service Automatic cleaning



45 minutes after a steam bath the steam generator's automatic cleaning routine starts. After that the steam generator is out of operation for 20 minutes.

During this time the **Steam** icon is inactive.



Press the Steam icon to view the remaining cleaning time in minutes. When the automatic cleaning routine has finished the **Steam** icon reactivates.

Removing limescale



Timer expired:
(130h)

Limescale must be removed regularly.

After 130 hours (a fixed setting) removal of limescale is possible or prior to 130 hours a manual removal of limescale can be carried out.

Note:

During limescale removal Profile and Hotel Mode are blocked.

When the timer runs out the steam generator locks.

The **Steam** icon is inactive.

Press the **Steam** icon.



Limescale removal **cannot** be started in Hotel Mode.

Press the **Please Service** icon to start the warming-up phase for the removal of limescale.



The steam generator heats up. **Hot** steam can emerge from the steam outlet.

After 20 minutes the warming-up phase for the removal of limescale stops.



The **Please Service Now** icon appears.

The **overall system may not be** disconnected from the mains.

You can now run the limescale removal routine for the steam generator. For more information on this procedure see the technical product information for the steam generator.



Note **Service in-progress** appears if the **Steam** icon is pressed while Service is active.



CAUTION: Hot


If the limescale removal routine has finished move to the Main Menu by pressing the **Back** icon.

The **Steam** icon is inactive.
The timer must be reset.

Press the inactive **Steam** icon for a few seconds until the **Timer** icon appears.

Press the **Timer** icon for a few seconds.

Reset timer



The timer is now reset to 130 hours once again.



Removing limescale



Manual:

Press the **Steam** icon for a few seconds.

Note:

During limescale removal Profile and Hotel Mode are blocked.


Limescale removal **cannot** be started in Hotel Mode.

The remaining time until the fixed interval appears.

Press the **Timer** for a few seconds.



Press the Service icon to start the warming-up phase for the removal of limescale.
During this time the system cannot be operated.





The steam generator heats up. **Hot** steam can emerge from the steam outlet. After 20 minutes the steam generator stops. The warming-up phase for the removal of limescale is finished.



The **Please Service Now** icon appears.

The **overall system may not be** disconnected from the mains. You can now run the limescale removal routine for the steam generator. For more information on this procedure see the technical product information for the steam generator.



Note **Service in-progress** appears if the **Steam** icon is pressed while Service is active.



CAUTION: Hot

If the limescale removal routine has finished move to the Main Menu by pressing the **Back** icon.

The **Steam** icon is inactive. The timer must be reset.

Reset timer



Press the inactive **Steam** icon for a few seconds until the **Timer** icon appears.

Press the **Timer** icon for a few seconds.



The timer is now reset to 130 hours once again.