





Troubleshooting

Symptom	Cause	
No flow or low flow rate	Partially closed isolation valve.	Ope
	Instantaneous water heater cycles on and off as flow rate or pressure is too low.	Incr
	Head of water is below the minimum distance required.	Refe
	Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Doı
	Airlock or partial blockage in the supply pipework.	Flus and
Water dripping from taps	This is normal for a short time after us- ing the taps.	This of w
	If water continues to drip, possibly due to the ceramic disc valves	Ren sect
Taps do not turn on	Closed isolation valve.	Ope
	Mains water supply turned off.	Turr

Notes

Our Guarantee

At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

To start your free guarantee simply scan the QR code and register your product. Alternatively visit www.bristan.com/register

For any other queries, please call our Customer Service on 0330 026 6273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit www.bristan.com/service-centre/guarantees.

Remedy

en isolation valve.

rease water flow rate or pressure through system.

fer to specification for minimum distance required.

not use other water outlets when using the taps.

ish through pipework to ensure removal of debris d any airlocks.

is is caused by residual water tension, the build up water in the tap body.

move valves and clean, refer to 'Maintenance' tion before starting any maintenance.

en isolation valve.

n on mains water supply.

Contact Us

BRISTAN

Bristan Group Ltd.

UK: Bristan Group, B78 1SG.

EU: Masco Europe S.à.r.l. 14 Rue Strachen 6933 Mensdorf Luxembourg

Customer Service: +44330 026 6273 Web: www.bristan.com Email: enquire@bristan.com

A Masco Company

