



INSTALLATION MANUAL














Eastbrook Code	Adjustment	Eastbrook Code	Adjustment
69.0047	490-500	69.0048	690-700
69.0049	750-760	69.0050	790-800
69.0051	890-900	69.0052	990-1000
69.0053	1190-1200	69.0054	1390-1400






F010



This product should only be fixed by a fully qualified installer


<p>8CE1</p>  <p>1X</p>	<p>8CE2</p>  <p>5X</p>	<p>8CE3</p>  <p>5X</p>	<p>8CE4</p>  <p>3X</p>	<p>8CE5</p>  <p>3X</p>	<p>8CE7</p>  <p>1X</p>	<p>8CE8</p>  <p>1X</p>
<p>8CE9</p>  <p>1X</p>	<p>8CE10</p>  <p>3X</p>	<p>8CE11</p>  <p>2X</p>	<p>8CE12</p>  <p>1X</p>	<p>8CE13</p>  <p>1X</p>	<p>8CE14</p>  <p>1X</p>	




Ø6



Ø3.2





LH



RH

1L




1.1

12mm

8CE1

1R




1.1

12mm

8CE1

2L




2.1



2.2

8CE2(4X)

2R
















2.1



2.2

8CE2(4X)


3L**3R****4L****4R****5L****5R**

6L



6.1




6.2




6.3

**6R**



6.1




6.2





6.3

**7L**


7.1

**7R**

7.1

**8L**



8.1




8.2



8.3

**8R**


8.1





8.2





8.3





9L





9R





10L





10R





11L





11R





12L





12R



13L





13R





14L

Silicone on the outside of the screen only



14R

Silicone on the outside of the screen only



Cleaning & Maintenance

Don't clean the shower enclosure with irritant detergent such as alcohol,bleach or other chemical cleaners.

Only clean with warm soapy water.

After the installation is completed,should you find that there is notable noise when the glass door moves,you may add a small quantity of lubricant onto the roller wheel,slipping hook and the track.

Helpline: 01452 317890