

General Cleaning


Bristan products are made from premium materials, with hand polishing and electroplated finishes.

Your taps or shower should be regularly cleaned with warm water, a mild pH-neutral liquid soap, and polished with a soft cloth. Any residues from soap, toiletries etc. should be rinsed off straight after use.


Household bleaches and cleaners contain harsh chemicals and may damage the surface finish. Avoid using abrasive cloths, scouring pads, scrub sponges, steel wool or anything similar.

Some surfaces such as nickel and pewter may be affected by the dye found in some cloths, so it is also important to avoid hanging cloths on spouts.

Operation



Maintenance - Cleaning/Repla




2

Remove cap and grub screw.
Remove handle.



IMPORTANT
Isolate the water supply before starting!

Rem
and
Remo



5

Replace cartridge, retaining nut and shroud.



Repla
ha


Alternative Installation for Surfaces Out of Tolerance/Extra Stability

Turn the hexagonal key anti-clockwise to remove the back nut from the EasyFit Base.


Feed the base through the top sink hole from the top.

REMEMBER
Make sure the base is centralised when viewed from the front of the tap.


Feed the Reinforcing Plate (if required) and Back nut up to the underside of the sink.




2




Feed the base through the top sink hole from the top.



Feed the Reinforcing Plate (if required) and Back nut up to the underside of the sink.



5



Love Your Chrome



Bristan offers an effective chrome-friendly cleaning kit for

Troubleshooting

Symptom	Cause(s)
No flow or low flow rate	Partially closed isolation valve.
	Instantaneous water heater cycles on flow rate or pressure is too low.
	Head of water is below the minimum required.
Water dripping from taps	Hot or cold water being drawn off else causing pressure changes or instantaneous boiler temperature changes.
	Airlock or partial blockage in the supply or hoses.
Water dripping from taps	Water supply failure
	This is normal for a short time after us
Water dripping from taps	If water continues to drip, possibly due to the ceramic disc valve