

SHIRES
BATHROOMS

**SHOWER TRAY
INSTALLATION INSTRUCTIONS**

BEFORE YOU START

We highly recommend that you thoroughly read these instructions before beginning the installation. Despite the comprehensiveness of these instructions, we advise that a technically skilled installer carry out this installation for optimal results.

Please check the shower tray and verify that it meets your desired specifications regarding its colour, size, shape, and type before unpacking. Additionally, please carefully inspect the tray for any signs of damage. If you find any issues, please do not proceed with the installation and promptly contact your local supplier for further

! IMPORTANT

If you plan to install the shower tray at an elevated level, use a panel riser kit that is suitable for the size and shape of your chosen tray. In case you are installing the shower tray with a steam unit, it is essential to ensure that the steam outlet is a minimum of 350mm away from the tray's top.

! SAFETY NOTES

Caution: Please exercise caution while drilling into walls or floors to prevent any damage to hidden pipes or electrical cables.

i CARE & USE OF YOUR SHOWER TRAY

Please keep these installation instructions for potential future reference and pass them on to the user. To maintain your shower tray's pristine condition for several years, please adhere to the simple cleaning procedure outlined below:

After use, it is common for small amounts of localized water to collect on the shower tray surfaces. Please wipe them dry immediately to prevent sediment build-up.

assistance.

Please verify that the top surface of the shower tray is suitable for use with your intended shower enclosure, taking into consideration the potential loss of dimension that may result once tiles or other materials have been installed.

When selecting your installation method, please ensure that you are capable of attaching or repairing your waste or waste outlet while it is in place.

While handling the shower tray, please exercise caution to prevent damaging the bottom edges. During installation, please take extra care to safeguard the visible surfaces against any impact damage or abrasions.

Kindly note that this product is quite heavy and will require two people to lift it safely.

The shower tray should be regularly cleaned using warm, soapy water and dried with a cloth. Please refrain from using scourers, abrasives, bleach, or other chemical cleaners, as they can cause damage.

TOOLS AND MATERIALS REQUIRED



Cement & Fine Sand



Anti-Crumbling Cement Additive



Trowel



Waste Unit



Spirit Level



Safety Eyewear



Silicone Sealant




Plywood Board (min. 18mm thick)

Note! Additional tools and materials may be necessary, depending on the specific requirements of the site.


SUSPENDED FLOOR INSTALLATION

1




We highly recommend installing all trays before tiling, as this will aid in establishing a water-tight seal around the tray. Position the shower tray onto the floor, taking care to ensure that the surface is level. Proceed to mark the tray's perimeter on the floor.

2




Remove the floor area (or a larger section) covered by the tray and replace it with a single, level piece of plywood, with a minimum thickness of 18mm. Place the plywood onto the floor and ensure that the area is flat and level. Position the shower tray onto the plywood, taking care to align it correctly, and mark the location of the waste hole.

3




Using your mark as a guide cut a hole large enough for waste unit to fit comfortably once tray is lowered in place. It's advisable to have access to waste once tray is in position to adjust and test tray after installation.

4




Attach the waste unit to the tray by following the instructions provided with the unit, taking care to safeguard the exposed threads. Prior to continuing, dry fit all components in their intended positions to guarantee compatibility. Then, secure the plywood into place by screwing it in position.

5




Prepare a workable mixture of fine sand, cement, and a cement additive as per the manufacturer's instructions. Using the trowel, evenly spread a layer of mortar, measuring between 5-10mm in thickness, over the entire area where the tray will be placed to provide complete support for the shower tray.

6



Carefully position the shower tray with waste installed onto the wet cement, ensuring that it is fully supported. Check the level of the top rims of the tray only, as it has a built-in fall to ensure adequate drainage. Remove any excess cement, and allow it to cure for 12 hours before proceeding with further installation.

7



Fit the waste. The shower tray and all connections must now be checked for water tightness, flow and adequate drainage over the entire area with the waste cover in position.



DO NOT PROCEED IF NOT SATISFIED.

After all checks and adjustments, it is recommended to silicone seal around the shower tray before tiling.

If fitting a shower enclosure, refer to the manufacturer's installation instructions.

TROUBLE SHOOTING

Q The waste outlet in the shower tray is directly over an obstruction at floor level.

A Consider switching to a Panel Riser Kit, or re-locating the shower tray.

Q The shower tray will not fit the space available.

A Consider recessing the edge of the tray into adjoining walls or using a smaller shower tray and enclosure.

Q There is water retaining on the surfaces of the tray.

A Check that the shower tray is level (top rims) as it is normal for small amounts of localised water to be retained.

Q Water will not flow fast enough down the waste outlet.

A Check that the waste unit is correctly installed and that the outlet pipe has sufficient angle and is not kinked or sagging causing an air blockage.

Q The enclosure will not fit on the shower tray.

A Check that the available surface on top of the tray is compatible with the size, shape and adjustment range of the enclosure.

Q Water escapes from a fitted walk-in or frameless enclosure.

A It is normal for spillage to occur from walk-in or frameless type enclosures, consider fitting a threshold seal on or changing to a fully framed enclosure.

Q Could I have a carpet on the floor in the bathroom?

A It is advised that you use only safety vinyl or tiled flooring in the bathroom area.